


**CARBONDALE AREA
CYBER ACADEMY**





Chromebook Tutorials

How to turn your device off.

First, hold the power button in the top right hand corner of the keyboard.



Next, a message will appear on the screen. Click on the power off option.



Lastly, the Chromebook's screen will turn black. Your device is now powered off.

